

EUROCOMPONENTS

Mounting instructions for v-rod lower handlebars and headlight fairing kit

Assembly should be performed by an authorized motorcycle technician

IMPORTANT: Please note that our headlight fairing kit does not fit on 2005-up B models, since they use a different headlight. It can be installed on pre-2005 B models without the need of our lower handlebars. Kit works on all other models with no problem; the use of our lower polished stainless steel handlebars is required for clearance reasons.

Kit includes:

- A) polished stainless steel handlebars
- B) paintable ABS fairing
- C) fairing mounting bracket (black powder coated)
- D) polished billet aluminium cover for steering head nut
- E) necessary hardware

Mounting instructions

- 1) disassemble the original handlebars together with the speedometer, exterior and interior casing, hand controls and grips.
- 2) disassemble the headlight together with the suspension fork and remove the plastic headlight casing from the original headlight insert.
- 3) our handlebars are prepared and drilled for internal wiring. In case the wires are to be mounted through the handlebars, this has to be done prior to the new assembly. Handlebars also feature dimples for original external wiring.
- 4) mount the new handlebars using the original M10 screws.
- 5) modify the exterior and interior casing of the speedometer unit as shown in **picture 1**. We recommend to mark each cut according to our description and to use an angle grinder for the cutting.
- 6) now exchange the original cover of the steering head nut with the provided aluminum cap. For this procedure it is necessary to reduce the diameter of locking plate. The plate must be covered completely by the new aluminum cap.
- 7) use the original M8 screws to mount the headlight bracket to the top tree, as shown in **picture 2**.
- 8) mount the hand controls and grips on the handlebars and then fix the speedometer unit to the exterior and interior casing. Lay all the cables toward the headlight. There will be enough space for the wiring harness under the fairing.
- 8) remove both side parts from our fairing bracket. They have to be attached on the right and left side of the headlight using the provided screws as shown in **picture C**. Now go on inserting the headlight into the fairing as shown on **picture 3**.
- 9) now the fairing can be mounted together with the headlight on the base of our bracket.
- 10) connect all the plug-in connectors to the headlight and fix the wiring harness under the fairing.

Notes

Headlight and fairing can be adjusted and tilted separately.

We recommend to use screw locking device and to apply all the torques indicated by Harley-Davidson when mounting the handlebars.



cut line



cut line

cut line

step 1
speedo unit exterior
and interior casings



cut line



step 2
mounting support
to the top tree



step 3
mounting both side
brackets to headlight



step 4
mounting headlight
into the fairing